

## ANNUAL INSPECTION SEALPAC



## ANNUAL INSPECTION

SafetyRespect Sealpac is valid for a period of 10 years, provided that it is inspected annually. Below is an instruction on how to perform the inspection.

1. Break the seal to open the box. Pull/twist the seal firmly 2-3 times to break it. Remove the inspection ring (manufacturing date).



2. Open the box and remove the inspection/document plastic bag. Remove the accessory bag. Have a look at the overall condition of the sealpac inside the drybag.

*Gently* remove the vacuum sealed pack out of the drybag.



**3.** Make sure that the Sealpac is not punctured or otherwise affected. The Sealpac should look like in the left picture. If the Sealpac looks like the pack in the right picture it has been punctured or otherwise affected, and lost its function. If this is the case it needs to be sent to SafetyRespect for full inspection and resealing.




**4.** Take the plastic seals out of the inspection plastic bag. Pull one seal out of the bundle and put the rest back in the bag. Take one of the stickers out of the inspection bag. Stick it on the first available spot and mark the next inspection date (1 year from the current inspection).



5. Mark the current month and year with the permanent marker from the inspection bag. Write your name and the date of the inspection below the sticker.

Take out the Mark Elephant manual from the inspection bag, and fill out the test report including the date of the current inspection, the date of next inspection, your name and the reason for this inspection.

Document the test protocol by taking a picture of it or by filling in the information from the test protocol in your chosen inspection log. Make sure that you have a notification system in place so you don't miss the planned inspection for next year!



6. Put the accessory bag and the inspection bag back in the box. Close the box and seal it with the correct seal.



The annual Sealpac inspection is now completed!